



ISO 标准气缸安装附件

CR 型附件



	缸径/型号 Inner Dia./Code												
	EM	HB	EA	TE	UL	PH	BT	RA	UR	GL	BR	CK	
	32	26	6.6	10	38	51	32	8	18	31	21	10	10
	40	28	6.6	12	41	54	20	10	22	35	24	11	12
	50	32	9	16	50	65	23	12	30	45	33	13	12
	63	40	9	16	52	67	25.5	12	35	50	37	15	16
	80	50	11	20	66	86	31.5	14	40	60	47	15	16
	100	60	11	20	76	96	37	15	50	70	55	19	20
	125	70	14	30	94	124	90	20	60	90	70	28.5	25
	160	90	14	36	118	156	115	25	88	126	97	31.5	30
	200	90	18		122	162	135	30	90	130	105	31.5	30